



Fig. 5a

Fig. 5b

Fig. 5c

Fig. 5d

Fig. 5e



Breaker

Fig. 6a

Fig. 6b

Fig. 6c

Stroker

## Pleasure – Breaker

1. Apply a touch of water-based lubricant to the Pleasure System Clip and the opening slit at the base of the Breaker. Slide the clip in, ensuring a snug fit.
2. Attach the Breaker onto the pocket of the Clip Harness. (see Fig. 6a)
3. Position it against the pouch, making contact with your most sensitive areas. (see Fig. 6b)
4. Press and rub your genital against the soft silicone. Whether you're exploring solo or igniting passion with a partner, the Breaker guarantees an adventure like never before.

## Pleasure – Stroker

1. Apply a touch of water-based lubricant to the Pleasure System Clip and the opening slit at the base of the Stroker. Slide the clip in, ensuring a snug fit.
2. Attach the Stroker onto the pocket of the Clip Harness. (see Fig. 6a)
3. Adjust the Stroker such that your growth clit can slide into the internally ribbed hole. (see Fig. 6c)
4. The Stroker mirrors cis-male penetration with a tantalizing suction effect. Apply some lube, slide in, and let the PeeCock shaft intensify your pleasure with every motion.

## Attachment – Clip Harness

1. Slide the bottom loop of the nylon strap through the horizontal opening on the FLY Clip and secure it with the plastic pin. (see Fig. 5a)
2. Thread both ends of the front nylon strap through the left and right vertical openings on the FLY Clip respectively as illustrated in Fig. 5b.
3. Attach the FLY clip onto the U tab of the PeeCock.
4. Fasten both ends of the nylon strap to the back waist nylon strap using the convenient clip and lock system on the left and right end. (see Fig. 5c).
5. Wear the harness like regular underwear and adjust the PeeCock to rest comfortably at your pubic region.

## Pleasure – Bullet Vibe

1. Press and hold the power button on the bullet and remote control for 3 seconds to turn on. (see Fig. 5d)
2. Cycle through the 10 settings with each click on the power button either on the bullet or remote control to select your favourite setting.
3. Place the bullet vibe into the pocket of the Clip Harness. (see Fig. 5e).
4. Position the bullet vibe to touch the sensitive spot of your genitalia area. ENJOY!